



#### 4. Tips for use:

- Attention: The Disto and transmitter are screwed together - the connection does not tolerate any force, so do not hold or move the unit by the Disto.
- The batteries in the Disto can only be changed by removing the Disto. To do this, carefully release the fitting screw on the back of the Disto and remove the Disto from the mounting unit. You can then remove the battery compartment cover on the Disto to access the batteries (see also Disto manual).

#### 5. Disto and WIN-GEPARD software:

##### **Installation:**

- Install the Bluetooth adapter on the PC (see also GEPARD installation manual).
- Switch on the Disto and activate Bluetooth on the Disto by pressing the Bluetooth button.
- Search for the Disto in the Bluetooth range on the PC and install (use the Bluetooth Manager!).
- **The main key for the Disto is '0000'.**
- Check the COM port assignment for the Disto: The COM port **MUST** be between #1 and #16. If this is not the case, the COM port **MUST** be changed in the WINDOWS device manager (see WINDOWS operating instructions)!!!

##### **Before starting:**

- Always switch the Disto on before starting the WIN-GEPARD software.
- Activate Bluetooth on the Disto by pressing the Bluetooth button.
- **Now start WIN-GEPARD.**
- **When you first start** the WIN-GEPARD software, you are asked whether you are using a Disto; **answer YES.**



- WIN-GEPARD will now automatically set up the Disto interface and the WIN-GEPARD software will search for the Disto.

